


User Instructions ClimaRad 4-position switch

Description and use

By way of the wireless RF 4-position switch the ClimaRad Fan, MiniBox or MaxiBox can be manually operated.



ClimaRad 4-position switch

The extraction fans work completely automatically as standard (in the 'Auto' position).

However by using the I, II and III (low, medium and high) positions, the extraction can be manually operated.

Position I can be used when you're absent, position II when you're present and position III during cooking or showering.

Setting options and operation of the ClimaRad 4-position switch

Button	times pressed	duration	action
I	1	<1s	Low position
II	1	<1s	Medium position
III	1	<1s	High position 30 min
III	2	<1s	High position
Auto	1	<1s	Auto position
Auto + III	1	3-4 s	Link

Depending on the need, it is possible to ventilate for 30 minutes in the cooking or shower position.

After 8 hours the auto position is automatically activated.

If a button is pressed longer than indicated, no action will be performed and the switch will go into standby mode to save battery power.

LED colour	flash	description
Green	1x	Position changed / Normal operation
Orange	1x	Low battery
Orange	2x	Start
Red	1x or 2x	Please contact your housing corporation/landlord

When the switch is correctly used the LED results are displayed as shown in the table.